






電視
安裝指南





BRAVIA

KD-65X7000E / 55X7000E



1

1




65


55



2




3




4


65



55




5




6

65




55




7



65



55




2




連接 關於額外的連接信息，請參閱使用說明書中的“連接圖”。

3




65





55

4






5

1





2

65




55





3


65



55



4



<http://www.sony-asia.com/support>