






電視
安裝指南



BRAVIA


KD-49X7500F / 43X7500F





參考指南

1


1




2




3




4




5




6



1.5 N·m/1.5 N·m
{15 kgf·cm}




2




連接 關於額外的連接信息，請參閱參考指南中的“連接圖”。



3




4



5



i



說明



<http://www.sony.net/tv-how-to-videos>

提示