






電視
安裝指南



BRAVIA




KD-65X7500F / 55X7500F




參考指南

1


1





1.5 N·m/1.5 N·m
{15 kgf·cm}




2





3





4





5




6





7



8




2




連接 關於額外的連接信息，請參閱參考指南中的“連接圖”。

3




4




5


1




2




3




1




2



4



i



說明



<http://www.sony.net/tv-how-to-videos>

提示